



## Accessories (Special order only)

### Smoke Relay Modules: SM120X

- Activates or deactivates auxiliary devices such as bells, lights and ventilation systems.
- For use with all interconnected installations that contain smoke alarms and smoke / CO combo units and heat detectors.
- The power supply portion of this module can be used with manual pull stations, flow switches, and spot type heat detectors.



SM120X

### CO Relay Modules: CO120X

- Activates or deactivates auxiliary devices such as bells, lights and ventilation systems.
- For use with all interconnected installations that contain CO alarms and smoke / CO combo units.
- CO relay modules should not be used to connect groups of CO alarms to an alarm panel or to interconnect groups of CO alarms together.



CO120X

### Remote Visual Signaling Device: SL1771

- Bright 177 Candela Strobe Light – Provides visual alarm to the hearing impaired. Strobe light is triggered when any interconnectable smoke, heat, or CO alarm with the home is activated.
- 1 Hz Flash Rate – Light level proven effective in alerting the hearing impaired. Sixty flashes per minute – meets recommended ULC standards. Different flash rate for CO and smoke situations.
- No relay required.



SL1771

### CO Relay Modules: HD135F

- Test Button – Tests heat detector circuitry and horn.
- 9V Battery Backup – For continuous protection in case of power failure.
- Alarm sounds when air temperature rises above 135°F. Ideal for garages and attics.
- No relay required.



HD135F

